

HY-PRO®

ELECTRIC AIR PUMP INSTRUCTION MANUAL

Please read this manual carefully before use.



Item No: HP10447




WARNING:

- Only to be used by an adult.
- Do not use or store the Electric Air Pump in direct sunlight, high temperatures or high pressure.
- Do not use or store the Electric Air Pump in wet conditions.
- Store in cool dry conditions.
- It is advisable to turn off the Electric Air Pump after 10 minutes of continuous use and allow it to cool for 30 minutes.
- Turn off the power switch after using.
- Read all warnings and instructions before use. Improper use may result in damage, excess heat, toxic fumes, fire or explosion.
- Do not leave on charge over night.
- Charge directly to the wall socket. Do not use extension leads.

THE AIR PUMP UNIT:



- 1 Air Hose
- 2 Heat Resistant Hose
- 3 Pressure Display
- 4 Operation Button
- 5 LED light
- 6 USB Charging Port
- 7 Type-C Charging Port - Works as a power bank
- 8 Electric outlet for cigarette lighter charging socket (optional)



TO SET PRESSURE PRE-SETS:

Long press "⏏" button to change the pressure unit. Press: "+" or "-" increase or decrease the target pressure, after numbers stop flashing, press "⏏" button to start inflation. When it reaches the desired pressure, it will stop automatically.



DIGITAL DISPLAY:




Digital display screen has four battery modes:

- First battery mark display: 100% > power > 70%.
- Second battery mark display: 70% > power > 40%.
- Third battery mark display: 40% > power > 10%.
- Fourth battery mark display flashing: Battery Power is less than 10%, need to recharge.


OPERATING GUIDE:




1 Screw the air hose into the pump unit.




2 Screw the air hose onto the car / bike tyre, or use the specific inflation nozzle provided.




3 To turn the unit on: Press and hold the Power Switch for 3 seconds.



4 Press "⏏" once to wake up the screen or start inflation.




5 Press "⏏" to change between the 4 different modes: Car Tyre, Bike Tyre, Motorcycle Tyre, Sports Ball.




6 Long press "⏏" for 3 seconds to change the units of pressure.



7 You can press "+" or "-" to increase or decrease the target pressure.



8 Short press "⏏" to start inflation.



9 When the real pressure reaches the target pressure, the pump will stop automatically. You can also stop inflation any time by pressing "⏏". Turn off the power switch by holding down "⏏".

4 INFLATION MODES:



CHARGING THE UNIT:

- The USB charging cable supplied with the electric air pump should be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage the pump must not be charged until the charging cable replaced.
- Use caution when charging.
- Do not overcharge as this will affect the life of the battery and may cause overheating which can lead to a fire hazard. Never charge near flammable materials or liquids.
- The best charging temperatures are between 0(°C) ~ 40(°C). Extreme cold and extreme heat will prevent your battery from charging fully.
- Use only the charging cable supplied by Hy-Pro. Use of any other charging cable may lead to damage to the product, overheating and risk of fire. Use of any other charging cable voids the warranty. If you spot any signs of wear and tear or damage, visit our website at www.zincsports.com or contact us at customerservices@zinchq.com to buy a replacement charging cable.
- The charging cable is not a toy, it should be operated by an adult.
- Once your pump has been charged, unplug the charging cable from the output charger (not supplied) and then from the pump. Do not leave the pump on charge overnight and do not leave the pump unattended whilst on charge.
- Ensure you have working smoke alarms on every floor of your home and in the room where you charge the scooter.
- In an ideal situation, you would have somewhere secure to store/charge your pump, such as a shed or garage. It would also be desirable for this area to have plugs where you can charge your pump.
- Plug the output charger (not supplied) into a main socket rather than an extension lead.
- Do not cover the product with anything while charging.
- Make sure you use the battery recommended by the manufacturer.

BATTERY WARNINGS:

- This product is not to be connected to more than the recommended number of batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before being charged.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

PRODUCT SPECIFICATION:

Model:	HP10447	Power:	50W
Material:	ABS	Battery Voltage:	3.7V
Dimension:	49 x 87 x 135mm	Battery Capacity:	2000mAh*2
Max. air pressure:	150psi	Charging time:	2 ~ 3 hours
Noise:	< 85dB	Use time per charge:	approximately 40min

You need help? For spare parts information and technical support, visit our website at www.hyprosports.com, or email us on info@hy-pro.co.uk